

PRIMER PU

PRIMER FOR SOLES FROM POLYURETHANE



DIRECTIONS FOR USE

Wash the soles with PRIMER PU by using hard brush. Better results are achieved by pressing the brush and washing for a second time the soles. Spread the adhesive on the soles 15 - 30 min after the washing. If the soles stay more than 30

min after the washing without spreading the adhesive on them, then they have to be washed with PRIMER PU again. For soles with large amount of ungluing it is suggest the double washing.

The technical information and instructions contained in the present brochure and referring to the application and end use of Thrakon products are based on the up to now know-how and experience of the Company with regards to the products and are provided in good faith as long as such products are stored, used and applied as per Thrakon recommendations. Due to the inability, on our part, to directly inspect the conditions prevailing at the worksite as well as the application procedures of the product, the Company does not provide any guarantee with regards to the adequacy of its products for specific purpose while the Company shall not bear any legal responsibility based on the information stated in the present brochure or any other written, oral, or otherwise provided recommendations and instructions. The users of the products are advised to perform a limited surface testing of the products adequacy for the eventual application and use intentions. Thrakon reserves the right to modify the features of its products without prior notification. All orders shall be approved only following acceptance of the above and under the eventual Commercial Policy terms of the Company. The issuance of the present brochure voids any prior version.