

PRIMER TR

PRIMER FOR SOLES FROM NATURAL OR THERMOPLASTIC RUBBER



DIRECTIONS FOR USE

The soles from Natural Rubber must be necessarily roughened, but not the soles from Thermoplastic Rubber. Wash the soles with PRIMER TR. The soles must be stayed at least 2 hours after the washing. The washed soles can also be used after 2 weeks. Take some PRIMER TR from the bottle

and put it in a glass. Apply immediately. Never return the PRIMER TR from the glass to the bottle. **WARNING:** PRIMER TR must be stored in a dark, cool place and the bottle must be closed well and hard. If PRIMER TR appears too much "salt" in the bottle, then do not use it.

The technical information and instructions contained in the present brochure and referring to the application and end use of Thrakon products are based on the up to now know-how and experience of the Company with regards to the products and are provided in good faith as long as such products are stored, used and applied as per Thrakon recommendations. Due to the inability, on our part, to directly inspect the conditions prevailing at the worksite as well as the application procedures of the product, the Company does not provide any guarantee with regards to the adequacy of its products for specific purpose while the Company shall not bear any legal responsibility based on the information stated in the present brochure or any other written, oral, or otherwise provided recommendations and instructions. The users of the products are advised to perform a limited surface testing of the products adequacy for the eventual application and use intentions. Thrakon reserves the right to modify the features of its products without prior notification. All orders shall be approved only following acceptance of the above and under the eventual Commercial Policy terms of the Company. The issuance of the present brochure voids any prior version.